TIME LAPSE CAMERA Controller Bundle




Quick Guide








Operating Camera



Operating BLE Controller







Note

FCC FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limit s for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit dierent from that to
 - which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Any changes or modications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement:

- This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

BSMI 有雷池產品

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

警告

太雷池如果更換不正確會有保性的合論、請依製造商證明書處理過之雷池。

NCC LP0002

低功率雷波輻射性電機管理辦法

第十二條 經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅自變更頻率、加 大功率或變更原設計之特性及功能。

第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時 · 應改善至無 干擾時方得繼續使用 · 前項合法通信 · 指依電信法規定作業之無線電通信 · 低功率射頻電機須忍受合法 · 孫信或丁峯 · 孔緣及聚據兩用電效輻射性觀影帽分干層 ·



Full Manual + **Tutorials**

https://brinno.com/pages/support-bcc200-ble



Register Online and get **Extra Months warranty**

http://www.brinno.com/support/registration



FAOs

https://brinno.com/pages/fag-bcc#BCC200-BLE



Time Lapse Calculator

https://www.brinno.com/support/time_setting_calculator



Contact customer service at: = Customerservice@brinno.com