

Camera Firmware Upgrade

Time Lapse Camera TLC120

version EN A1 Jul. 18, 2017

Before doing camera firmware upgrade process, please follow below steps and unzip the firmware upgrade package.

Step 1 Turn off camera power, remove the SD card from camera and insert into a PC.




Step 2 Copy and save the file **TLC120FW.BIN** into **120TLC00** folder in the SD card (120TLC00 folder should locate in the **DCIM** folder)
** If the SD card doesn't have a folder named 120TLC00 in the DCIM folder, please create those folders by yourself.



Step 3 Insert SD card into camera and turn on camera power.



Step 4 Firmware upgrade is processing, the LED indicator will blink green and orange color in several seconds, please do not turn off power or remove SD card. Upgrade completed, the LED will stop blinking and turn to green.




Done Please connect your smart phone to camera to make sure the upgrade was successfully completed.



HOW TO CHECK CAMERA FIRMWARE VERSION?

1. Open Brinno Camera app
2. Go to Menu Settings
3. Go to General Settings
4. Scroll down to verify camera version



Please do not TURN OFF power or REMOVE SD card when camera is updating firmware as that will damage the camera!

Supports: customerservice@brinno.com

www.brinno.com